



INSTALLATION

Plug the supplied AC/DC adaptor (Model No. 2T0069) to an AC household outlet, and then plug the DC jack to the back of the unit. Your clock is ready to work for you.

TO SET TIME AND THE SNOOZE DURATION

1. Press **SET** once, the hour digits “0” flash. Press ▲ or ▼ to set the time in hours (hold to advance rapidly).
2. Press **SET** again, the minute digits “00” flash. Press ▲ or ▼ to set the time in minutes. (hold to advance rapidly).
3. Press **SET** again, the display shows “24Hr” and flashes. Press ▲ or ▼ to select “12Hr” or “24Hr” time format. If “12Hr” is selected, the **AM** will appear on the upper left to indicate the morning time and **PM** will appear on the upper right to indicate the afternoon.
4. Press **SET** again, the display shows “05” and flashes. Press ▲ or ▼ to select your snooze time from 5 to 60 minutes.
5. Press **SET** again or if no key pressed for approx. 10 seconds to exit the setting mode.

TO SET THE ALARM

1. Press and hold **AL SET / AL STOP**, **AL** appear and the alarm’s hour digits flash. Press ▲ or ▼ to set the alarm in hours. (Hold ▲ or ▼ to advance rapidly).
2. Press **AL SET / AL STOP** once again, the minute digits flash. Press ▲ or ▼ to set the alarm in minutes. (Hold ▲ or ▼ to advance rapidly).
3. Press **AL SET / AL STOP** again, LED displays “HI” (vibration at HI level), press ▲ or ▼ to select “LO” (vibration at Lo level).
4. Press **AL SET / AL STOP** once again, LED displays “F-1 (ex. 800 Hz)” and flash, press ▲ or ▼ to select the alarm tone (frequency) :
F-1 (low tone, 800 Hz),
F-2 (mid tone, 1 KHz),
F-3 (high tone, 1.5 KHz)
5. Press **AL SET / AL STOP** again, LED displays “L1” (for the Low ringer level), press ▲ or ▼ to select “L3” (for the high ringer level)
6. Press **AL SET / AL STOP** once again to exit the alarm setting, also if no buttons are pressed for around 10 seconds this will also exit the alarm setting mode.

TO TURN ON/OFF AND SELECT THE ALARM MODE

1. At normal time display mode, press **AL SET / AL STOP** one at a time to activate the alarm(s) and turn on corresponding alarm indicator(s) on the lower part of the display:

⏰	: only shaker activated
⏰ 🔊	: both sound and shaker alarm activated
⏰ ☀️	: both strobe light and shaker alarm activated
⏰ 🔊 ☀️	: strobe light, sound and shaker alarm activated

2. Press **AL SET / AL STOP** once more to turn off all the alarms, all ⏰, 🔊 and ☀️ alarm indicators are turned off.

Note: To use the shaker alarm, please plug in the shaker plug to the back of the clock. If user doesn’t want to use the shaker alarm, unplug the shaker plug from the clock.

TO STOP AND RESET THE ALARM TO COME ON THE NEXT DAY

When alarm is sounding, the corresponding alarm indicator flashes. Press **AL SET / AL STOP** once to stop the alarm and reset it to come on the following day. After that, the corresponding alarm indicator stays on the display.

TO USE SNOOZE (default snooze duration is 5 minutes)

When the alarm is sounding, press **Zz • ☀️** once, the alarm will stop temporarily and the corresponding alarm indicator will keep flashing. The alarm will come on again after the set snooze duration is over.

TO USE THE HI-MED-LO DIMMER (LED TIME DIGITS)

There is a 3-level brightness control for the LED clock display. Press **Zz • ☀️** to adjust the brightness (**HI / MED / LO**) on the LED display. The brightness adjustment can only be done when the brightness starts at **HI** position.

TO USE THE RING OF LED LIGHT

Press and hold **Zz • ☀️** button to turn on the ring of LED light, the brightness level of the LED ring (Hi-Med-Lo) corresponds to the time display brightness (Hi-Med-Lo). When the LED ring lights up, press **Zz • ☀️** button one at a time to adjust time display brightness and LED ring brightness accordingly. Press and hold **Zz • ☀️** button to turn off the ring of LED light. (The LCD dimmer automatically adjusts after the RED LED light is switched off).

CHARGE YOUR MOBILE PHONE WITH USB PORT

Connect the charging cable of your mobile phone to the USB port at the back of the clock and then connect the other end to the micro USB charging socket on your mobile phone. The clock will charge the mobile phone automatically.

Note:

1. Make sure the cable supplied with your mobile phone is used for charging.
2. Make sure the adaptor supplied with this clock (5V 1.2A) is used to power it.
3. It is not possible to charge an iPad® or notepad from the USB socket on this clock.
4. When the alarms are sounding/active you can not charge phones etc using the USB port.

TEST MODE

Press and hold ▲/ **TEST** button, strobe light flashing, shaker vibrating and buzzer sounding.

TROUBLE SHOOTING

Your clock may display the incorrect time or may not function correctly due to electro-static discharge or other interference like an electrical surge when an electric timer or heater switches on/off (poor mains filtering). The mains adapter for the clock should only be plugged into a mains wall socket, not a mains extension that is shared with electric heater (or other high wattage equipment).

CARE OF YOUR PRODUCT

1. Place your clock on a stable surface, away from sources of direct sunlight or excessive heat or moisture.
2. Protect your furniture when placing your unit on a natural wood and lacquered finish by using a cloth or protective material between the unit and the furniture.
3. Clean your unit with a soft cloth moistened only with mild soap and water. Stronger agents such as benzene, cleaners containing alcohol, thinners or similar materials can damage the surface of the unit.

SPECIFICATIONS

Alarm duration	: 1 hour	
Snooze duration Adjustable	: 5 to 60 minutes	
Default settings	Time format	24 hour
	Time	0:00
	Alarm	6:00
	Alarm and shaker level	HI
	Alarm sound frequency	F-1
	Alarm sound level	L1 (low)
Audible alarm	Snooze duration	05 (5 minutes)
	: up to 95 dBA at 1m	

Express Warranty (Australia)

This Express Warranty is provided by Oricom International Pty Ltd ABN 46 086 116 369, Unit 1, 4 Sovereign Place, South Windsor NSW 2756, herein after referred to as “Oricom”.

Oricom warrants that the product is free from defects in materials or workmanship during the Express Warranty Period. This Express Warranty does not extend to any product from which the serial number has been removed or was purchased outside of Australia.

The benefits of this Express Warranty are in addition to other rights and remedies you may have under the Australian Consumer Law. Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure. In the event of a minor failure, Oricom reserves the right to choose to repair or replace the product.

The Express Warranty Period will be a period of 12 months beginning on the date of purchase of the product evidenced by your dated sales receipt. You are required to provide proof of purchase as a condition of receiving Express Warranty services.

You are entitled to a replacement product or repair of the product at our discretion according to the terms and conditions of this document if your product is found to be faulty within the Express Warranty Period. This Express Warranty extends to the original purchaser only and is not transferable.

Products distributed by Oricom are manufactured using new materials or new and used materials equivalent to new in performance and reliability. Spare parts may be new or equivalent to new. Spare parts are warranted to be free from defects in material or workmanship for thirty (30) days or for the remainder of the Express Warranty Period of the Oricom branded product in which they are installed, whichever is longer. During the Express Warranty Period, Oricom will where possible repair and if not replace the faulty product or part thereof. All component parts removed under this Express Warranty become the property of Oricom. In the unlikely event that your Oricom product has a recurring failure, Oricom may always, subject to the Competition and Consumer Act 2010, at its discretion, elect to provide you with a replacement product of its choosing that is at least equivalent to your product in performance.

No change to the conditions of this Express Warranty is valid unless it is made in writing and signed by an authorised representative of Oricom.

Oricom will not be liable under this Express Warranty, and to the extent permitted by law will not be liable for any defect, loss, damage or injury arising out of or in connection with a:

1. Failure by you to adhere to the warnings and follow the instructions set out in this user guide for the proper installation and use of the product;
2. Willful misconduct or deliberate misuse by you of the product;
3. Any external cause beyond our control, including but not limited to power failure, lightning or over voltage; or
4. Modification to the product or services carried out on the product by anyone other than Oricom or Oricom’s authorised service provider.

How to make a claim under your Express Warranty in Australia

Oricom has a simple warranty process for you to follow:

- Please call or email our Customer Support Team, 02 4574 8888 or support@oricom.com.au.
- A Customer Support Team member will verify after troubleshooting with you if your product qualifies under warranty. If so, they will give you a Product Return Authorisation number.
- We will then email a Return Authorisation form and a Repair Notice (if necessary), together with instructions on how to return the product for warranty service.

Please note that if a Customer Support Team member advises that your product does not qualify for return, this warranty does not apply to your product. Products that are authorised to be returned to Oricom in Australia must include all of the following:

- A completed Return Authorisation form
- A copy of your Proof of Purchase (please keep your original copy)
- The faulty product, including all accessories.

Send the approved returns to:

Oricom International Pty Ltd
Locked Bag 658
South Windsor NSW 2756 Australia

Please note that this Express Warranty excludes expenses incurred by you in returning any faulty product to us. You must arrange and pay any expenses incurred (including postage, delivery, freight, transportation or insurance of the product) to return the faulty product to us, however, we will arrange delivery of the repaired or replaced faulty product to you.

Important Information

Repair Notice

Please be aware that the repair of your products may result in the loss of any user-generated data (such as stored telephone numbers, text messages and contact information). Please ensure that you have made a copy of any data saved on your product before sending for repair. Please also be aware that products presented for repair may be replaced by refurbished products or parts of the same type rather than being repaired.

